

**Setup function                      Settings & options (factory default in bold)**

- |   |   |
|---|---|
| <b>1 System type</b>  | <ul style="list-style-type: none"> <li>0 1 heat/1 cool conventional</li> <li>1 1 heat/1 cool heat pump (no aux. heat)</li> <li>2 Heat only — 2-wire systems, 3-wire zone valves (Series 20), and normally open zone valves</li> <li>3 Heat only with fan</li> <li>4 Cool only</li> <li><b>5 2 heat/1 cool heat pump (with aux. heat)</b></li> <li>6 2 heat/2 cool conventional</li> <li>7 2 heat/1 cool conventional</li> <li>8 1 heat/2 cool conventional</li> </ul> |
| <b>2 Changeover valve (O/B terminal)</b>                          | <ul style="list-style-type: none"> <li>0 Changeover valve (O/B terminal energized in cooling)</li> <li><b>1 Changeover valve (O/B terminal energized in heating)</b></li> </ul>   |
| <b>3 Fan control (heating)</b>                                    | <ul style="list-style-type: none"> <li><b>0 Gas or oil furnace — equipment controls fan in heating</b></li> <li>1 Electric furnace — thermostat controls fan in heating</li> </ul>  |
| <b>5 Stage 1 heat cycle rate (CPH: cycles/hour)*</b>              | <ul style="list-style-type: none"> <li><b>5 For gas or oil furnaces of less than 90% efficiency</b></li> <li>1 For steam or gravity systems</li> <li>3 For hot water systems &amp; <u>furnaces of over 90% efficiency</u></li> <li>9 For electric furnaces</li> </ul>   |
| <b>6 Stage 2 heat cycle rate/Auxiliary heat cycle rate (CPH)*</b> | <ul style="list-style-type: none"> <li><b>5 For gas or oil furnaces of less than 90% efficiency</b></li> <li>1 For steam or gravity systems</li> <li>3 For hot water systems &amp; <u>furnaces of over 90% efficiency</u></li> <li>9 For electric furnaces</li> </ul>   |
| <b>8 Emergency heat cycle rate (CPH)*</b>                         | <ul style="list-style-type: none"> <li><b>9 For electric emergency heat</b></li> <li>1 For steam or gravity systems</li> <li>3 For hot water systems &amp; <u>furnaces of over 90% efficiency</u></li> <li>5 For gas or oil furnaces of less than 90% efficiency</li> </ul>   |
| <b>9 Stage 1 compressor cycle rate (CPH)</b>                      | <ul style="list-style-type: none"> <li><b>3 Recommended for most compressors</b></li> <li>[Other cycle rate options: 1, 2, 4, 5 or 6 CPH]</li> </ul>  |
| <b>10 Stage 2 compressor cycle rate (CPH)</b>                     | <ul style="list-style-type: none"> <li><b>3 Recommended for most compressors</b></li> <li>[Other cycle rate options: 1, 2, 4, 5 or 6 CPH]</li> </ul>  |
| <b>12 Manual/Auto changeover</b>                                  | <ul style="list-style-type: none"> <li>0 Manual changeover (Heat/Cool/Off)</li> <li><b>1 Auto changeover (Heat/Cool/Auto/Off)</b></li> <li>2 Auto changeover only (Auto)</li> </ul>   |
| <b>14 Temperature display</b>                                     | <ul style="list-style-type: none"> <li><b>0 Fahrenheit</b></li> <li>1 Celsius</li> </ul>  |
| <b>15 Compressor protection</b>                                   | <ul style="list-style-type: none"> <li><b>0 No compressor off time</b></li> <li>[Other options: 1, 2, 3, 4, or 5-minute off time]</li> </ul>  |
| <b>26 Auxiliary heat control</b>                                  | <ul style="list-style-type: none"> <li><b>0 Comfort</b></li> <li>1 Economy</li> </ul>   |
| <b>27 Heat temperature range stops</b>                            | <ul style="list-style-type: none"> <li><b>90 Max. heat temperature setting is 90° F (32° C)</b></li> <li>[Other options: 40° F to 89° F (4.5° C to 31.5° C)]</li> </ul>   |
| <b>28 Cool temperature range stops</b>                            | <ul style="list-style-type: none"> <li><b>50 Min. cool temperature setting is 50° F (10° C)</b></li> <li>[Other options: 51° F to 99° F (10.5° C to 37° C)]</li> </ul>  |

\*[Other cycle rate options: 2, 4, 6, 7, 8, 10, 11 or 12 CPH]

